


80cm 5 zone induction cooktop with Wi-Fi connected CookSmart Touch display, DoubleBridge zones and built-in assisted cooking functions



Product Details

FEATURES

CookSmart Touch

SenseFry

DoubleBridge function

MaxiZone

PowerBoost

Hob2Hood technology

BENEFITS

3 YEAR WARRANTY

Because peace of mind should last as long as great design, this product has three years of trusted Electrolux support.

*Available for purchases after 1 March 2026.

SMART SENSORS, OPTIMAL RESULTS

No more boil-overs or burnt food. With SenseBoil & Fry, smart sensors intuitively lower the cooktops heat, preventing your pot from boiling over or your fried food from burning for even and consistent results

FULL-COLOUR, FULL CONTROL

The CookSmart Touch Display makes it easy to control your cooking. Select temperatures, zones and other smart functions on the full-colour display or connect to the app for a truly intuitive kitchen experience.

GUIDED COOKING MADE EASY

Assisted cooking functions automatically choose the best settings for your dish. With step-by-step guidance, its easy to try new recipes and achieve consistently delicious results.

HANDS-FREE HOOD

The hoods fan speed adjusts automatically while you cook, keeping the air clean and fresh so you can focus on your favourite dishes.

SEAR. STIR-FRY. BOIL.

Instant heat when you need it. PowerBoost delivers a quick burst of heat for rapid boiling, searing, and stir-frying, then automatically adjusts to keep your cooking steady.

TIMED TO PERFECTION

Set individual timers for each cooking zone that automatically switch off when time is up. Perfect for multi-tasking, whether preparing for dinner party guests or a family gathering.

Specifications

PRODUCT PROFILE

Domestic warranty details (yrs)	3
Cooktop type	induction
Materials/Colour	black ceramic glass

DIMENSIONS

Total product height (mm)	49
Total product width (mm)	780
Total product depth (mm)	520
Cut out width (mm)	750
Cut out depth (mm)	490
Cut out height (mm)	44

CONTROLS

Controls of Cooktops	Colour TFT Touchscreen
Functions of Cooktops	timer,acoustic signal,automatic switch off,pause,Hob2Hood,Melting,Bridging,PowerBoost,MaxiZone,Child-lock,Individual zone timers,Pot detection,SenseBoil & Fry
Indicators/display	3 level residual heat indicator
Features of Cooktop	safety cut off,electronic timer,minute minder,safety child lock,function lock,hot surface indicator,key lock function,sound off,MaxiZone,Hob2Hood,Bridge zone

ELEMENTS/BURNERS

LEFT FRONT ZONE

Left front zone	Bridge
Left front Watts	2300
Left front boost watts	3200
Left front diameter mm	210

LEFT REAR ZONE

Left rear zone	Bridge
Left rear watts	2300
Left rear diameter mm	210

CENTRE REAR ZONE

Centre rear zone	MaxiZone
Centre rear Watts	2300
Centre rear diameter mm	210

RIGHT FRONT ZONE

Right front zone	Bridge
Right front Watts	2300
Right front diameter mm	210

RIGHT REAR ZONE

Right rear zone	Bridge
Right rear watts	2300
Right rear diameter mm	210

ELECTRICAL SPECIFICATIONS

Connected load KW	7.35
Type of connection	hardwired

SHIPPING


Shipping Weight (Kg)	14
Pack Dimensions Height (mm)	118
Pack Dimension Width (mm)	868
Pack Dimension Depth (mm)	600

STUFFING QUANTITIES

20ft	308
40ft	700

Dimensions

Model:
KIS8759



Please note! Dimensions to be used as a guide only. All customers MUST refer to the user manual supplied with the product for detailed installation instructions.
© 2025 Electrolux S.E.A. PTE. LTD. ELX_IM_Diag_KIS8759_Aug25

Terms and Conditions

IMPORTANT

This is a guide of product dimensions only. For complete installation instructions, refer to the manual provided with product.

PRODUCT INFORMATION

The descriptors and illustrations in this publication apply to the specific products and models described as at the date of issue. Under our policy of continuous product development, product specifications may change without notice. Prospective purchasers should therefore check with their retailer to ensure this publication correctly describes the products that are being offered for sale. All information supplied is to be used for general reference purposes only and is on the understanding that Electrolux Home Products Pty Ltd (Australia) and Electrolux (NZ) Ltd (New Zealand) will not be liable for any loss, liability or damage of whatever kind arising as a result of reliance on such information. Colours of products illustrated are as close as printing limitations allow. Electrolux will at all times comply with its obligations pursuant to law including Trade Practices (Australian Consumer Law) Act and Regulations.

WARRANTY

This warranty only applies to Appliances purchased and used in Australia or New Zealand and used in normal domestic applications and is in addition to (and does not exclude, restrict, or modify in any way) any non-excludable statutory warranties in Australia or New Zealand. All warranties are subject to the conditions set out in the warranty card accompanying the product when purchased.

ELECTROLUX HOME PRODUCTS AUSTRALIA

telephone: 1300 363 640

fax: 1800 350 067

email: customercare@electrolux.com.au

web: www.electrolux.com.au

ELECTROLUX HOME PRODUCTS NEW ZEALAND

telephone: 09 573 2230

fax: 09 573 2221

email: customercare@electrolux.co.nz

web: www.electrolux.co.nz